

# ADAPTERS - TRANS MULTI-MODE / TRANS PRO +



PART #	QTY.	DESCRIPTION	PICTURE	APPLICATION
0130-02-01-0	1	TRANS ADAPTER KIT STANDARD		
1419-98-00-3	1	M14 CAPNUT (USE WITH BANJO BOLT 6007-14-20-3)		IMPORT
1602-14-00-2	3	M14 COPPER WASHER (USE WITH BANJO BOLT 6007-14-20-3)		IMPORT
2025-12-20-0	1	QUICK DISC. PLUG S/25 X 1/4" FPT		DOMESTIC
2025-13-20-0	2	QUICK DISC. PLUG S/25 X 1/4" MPT		DOMESTIC
2025-32-22-0	1	QUICK DISC. PLUG S/25 X 3/8" FPT		DOMESTIC
	1	QUICK DISC. PLUG S/25 X 3/8" MPT		DOMESTIC
2030-31-21-0	1	DRAIN HOSE ASSY S/48 X 9" HOSE		DRAIN WASTE TANK
2102-07-20-1	3	1/2" TO 29/32" HOSE CLAMP		GENERAL
6007-14-20-3	1	M14 BANJO BOLT (LONG)		IMPORT
6301-01-01-3	1	#6 FEMALE X SAE 45 DEG. FLARE		DOMESTIC- IMPORT
6302-02-01-3	1	5/8"-18 FEMALE X 45 DEG. INVERTED FLARE (SHORT)		DOMESTIC- IMPORT
6303-06-01-7	1	1/4"(M6) OPEN END HOSE ASSY		GENERAL
6303-08-01-7	1	5/16"(M8) OPEN END HOSE ASSY		GENERAL
6303-10-01-7	1	3/8"(M10) OPEN END HOSE ASSY		GENERAL
6303-12-01-7	1	1/2"(M12) OPEN END HOSE ASSY		GENERAL
6304-06-01-3	1	1/4"(M6) BARB ASSY		GENERAL
6304-08-01-3	1	5/16"(M8) BARB ASSY		GENERAL
6304-10-01-3	1	3/8"(M10) BARB ASSY		GENERAL
6306-03-01-0	1	5/16" X 90 FEMALE SNAPLOCK ASSY		DOMESTIC
6306-05-01-0	2	3/8" X 90 FEMALE SNAPLOCK ASSY		DOMESTIC
6306-08-01-0	1	1/2" X 90 FEMALE SNAPLOCK ASSY		DOMESTIC
6307-03-01-3	1	5/8"-18 MALE (LONG) INVERTED FLARE		FORD
6307-04-01-3	1	5/8"-18 FEMALE X SAE INVERTED FLARE		FORD
6308-02-01-3	1	1/2"-20 FEMALE SAE INVERTED FLARE (SHORT)		DOMESTIC/ IMPORT

# ADAPTERS - TRANS MULTI-MODE / TRANS PRO +



PART #	QTY.	DESCRIPTION	PICTURE	APPLICATION
6308-03-01-3	1	1/2"-20 FEMALE SAE INVERTED FLARE (LONG)		FORD
6308-04-01-3	1	1/2"-20 MALE SAE INVERTED FLARE (LONG)		FORD
6308-14-21-3	2	M14 BANJO FITTING ASSY		IMPORT
6310-10-08-3	1	3/8"MALE X 5/16" MALE SNAPLOCK		DOMESTIC/ IMPORT
6310-12-01-3	1	1/2" MALE SNAPLOCK		CHRYSLER V10 DIESEL
6310-16-01-3	1	M16 FEMALE SWIVEL ASSY		IMPORT
6311-01-01-3	1	3/8" MALE ANGLE STEP SNAPLOCK		GM
6312-01-01-3	1	1/2" MALE ANGLE STEP SNAPLOCK		GM
6313-01-01-3	1	# 5 FEMALE 45 DEG. FLARE		DOMESTIC/ IMPORT
6313-02-00-3	1	# 5 X # 6 SAE UNION		CHRYSLER/ FORD
6318-05-01-3	1	1/2"-20 MALE INVERTED FLARE (SHORT)		DOMESTIC/ IMPORT
6318-06-01-3	1	5/8"-18 MALE X 45 DEG. INVERTED FLARE (SHORT)		DOMESTIC/ IMPORT
6319-06-00-4	1	3/8" MALE (SMALL ANGLE STEP) SNAPLOCK		FORD
<b>FORD</b> (Include in Standard Adapter Kit 1/12)				
6319-08-00-4	1	1/2" MALE (SHORT ANGLE STEP) X 3/8" SNAPLOCK		FORD
6319-09-00-4	1	1/2" MALE (LONG ANGLE STEP) X 3/8" SNAPLOCK		FORD
6320-01-00-3	1	1/2"-20 FEMALE X 3/8" SNAPLOCK		FORD
6320-02-01-3	1	1/2" - 20 MALE X 3/8" SNAPLOCK		FORD
6321-14-01-3	1	M14 FEMALE SWIVEL ASSY.		FORD
6322-14-01-3	1	M14 MALE ASSY.		FORD

# ADAPTERS - TRANS MULTI-MODE / TRANS PRO +



PART #	QTY.	DESCRIPTION	PICTURE	APPLICATION
<b>OPTIONAL ADAPTERS</b>				
<b>BMW</b>				
6306-10-01-4	1	.575" ID X 3/8" SNAPLOCK		BMW
6306-11-00-4	1	.562" OD MALE X 3/8" SNAPLOCK		BMW
<b>MERCEDES</b>				
6312-12-01-4	1	.560" ID FEMALE ANGLE STEP X 3/8" SNAPLOCK		MBZ
6312-13-01-4	1	.545" OD MALE ANGLE STEP X 3/8" SNAPLOCK		MBZ
<b>LEXUS</b>				
6115-09-01-3	1	DRAIN INSERT #5 (M14-1.50)		LEXUS/ TOYOTA
6115-15-01-3	1	DRAIN INSERT #8 (M18-1.50)		LEXUS/ TOYOTA
6308-08-21-0	1	PRESSURE ASSY		LEXUS/ TOYOTA
6300-00-90-2	2	12" EXTENSION HOSE (RED)		LEXUS/ TOYOTA
6300-00-30-0	1	90 DEGREE SWIVEL X 7 1/2" RED X S/25 PLUG		LEXUS/ TOYOTA
<b>VOLVO</b>				
6323-12-01-4		M12 X 3/8" MALE SNAPLOCK ASSY (CLEAR)		VOLVO
6324-12-01-4		M12 FEMALE X 3/8" SNAPLOCK ASSY (CLEAR)		VOLVO
<b>VW</b>				
6300-01-00-3	1	VOLKSWAGEN (ZINC)		VW

## AEC GROUP INC.

3600 W. Carriage Dr.  
Santa Ana, CA 92704  
Ph. 877.906.1395 / Fax. 714.444.1396